MisuraEmme

Installation ECadLite program

- 1. Download, unzip the installation
- 2. Start the setup, making sure there is an internet connection
- 3. Choose your language

Seleziona la lingua dell'installazione X]
	Seleziona la lingua da usare durante l'installazione.	(
	English ~	l
	OK Annulla	

Select the language to be used during the istallation.

4. Check that the computer on which you are installing meets the minimum requirements and if so, click on next



5. Select the installation path, it is advisable to leave the one proposed in automatic, then click on next

💷 Setup - misuraemme	_		×
Select Destination Location Where should Setup misuraemme be installed?			
Setup will install Setup misuraemme into the following	folder.		
We recommend the installation in the suggested path (Evolutio	n\misur	aemme)	
c:\evolution\misuraemme	Br	owse	
At least 34,6 MB of free disk space is required.			
< Back Nex	t>	Can	icel

6. Select the type of installation, for all standard cases that is fine automatically proposed, or "Local", then click on next

📙 Setup - misuraemme	- 🗆 X			
Select Installation Type and Data Lo What type of installation do you be installed/located?	cation want to execute? Where should data files			
Installation Type				
Local	Choose this installation type if you will			
◯ Client	use the application only from this workstation.			
Setup will install data files into th	ne following local folde			
To continue, click Next. If you would like to select a different folder, click Brc				
c:\evolution\misuraemme	Browse			
	Map net drive			
	< Back Next > Cancel			

7. Choose to create an icon on the desktop, recommended option, and click on next.



8. Click on installation to start the installation

📙 Setup - misuraemme 🦳 —		×		
Ready to Install Setup is now ready to begin installing Setup misuraemme on your computer.				
Click Install to continue with the installation, or click Back if you want to review or change any settings.				
Destination location: c:\evolution\misuraemme	1	`		
Additional tasks: misuraemme Create a desktop shortcut				
<	>	,		
< Back Install	Car	ncel		

9. Start the program and fill in the form with the requested data, then click Request Activation

User data setting (Version 4.1.803 2022-06-23)			
eMail address*			
Company Name*			
Address			
Zip Code	City		District
Country			PC WSCRISTINA
Telephone	Fax		Web
PC Serial Number	307C-559B_MISURAEMME	Language	EN ~
Activation			Request Activation Code
Retailer User info			
	* required field		
Software License	Agreement		
By using this softw	vare, you indicate your acceptanc	e of the License A	Agreement.
END-USER LICENSE AGREEMENT FOR DAU eCad			
IMPORTANT-READ CAREFULLY:			
This Dau Software License Agreement ("DSLA") is a legal agreement between you (either an individual or a single entity) and Dau S.r.1. for the Dau software product identified above, which includes computer software and associated media and printed materials, and may include "online" or electronic documentation ("SOFTWARE PRODUCT" or "SOFTWARE").Bv installing. copving. or otherwise using • Reject • Laccept Conditions			

10. Once you receive the message that your request was successful, please wait the email with the activation code, copy it in the space marked as activation of the form, click on activate at the bottom right and then on exit

User data setting (Ve	rsion 4.1.803 2022-06-23)			
eMail address*	gabriele.invernizzi@misuraemme.it			
Company Name*	Misuraemme S.p.A.			
Address				
Zip Code	City		_	District
Country			PC WSCRISTIN	A
Telephone			Web	
	307C-559B_MISURAEMME	Language	EN	~
Activation	15A5C8477E66B10CA628		Reques	t Activation Code
Retailer User info	1			
* required field				
Software License	Agreement			
By using this software, you indicate your acceptance of the License Agreement.				
END-USER LICENSE AGREEMENT FOR DAU eCad				
IMPORTANT-READ CAREFULLY:				
This Dau Software License Agreement ("DSLA") is a legal agreement between you (either an individual or a single entity) and Dau S.r.l. for the Dau software product identified above, which includes computer software and associated media and printed materials, and may include "online" or electronic documentation ("SOFTWARE PRODUCT" or "SOFTWARE").Bv installing. copving, or otherwise using O Reject O Reject Print Cond. Close Activate				

11. At this point you have to wait for the request to be approved. Until it is not issues the following warning message.



Thanks for the attention,

contact our costumer service for further support: ict@misuraemme.it

MisuraEmme